LIV

User's Manual

Quartz Chronograph LIV Caliber 18

LIV

User's Manual

INTRODUCTION

We are a bold new brand with clean lines and meticulous attention to detail. We've set out to design watches that speak to the people who live life to the extreme. We examined each detail of a timepiece and set out to infuse it with thoughtfulness and style, making watches that make as much sense as they make a statement. Congratulations on your purchase, we are sure your new watch will bring you much satisfaction!

INDEX

1	PARTS OF YOUR NEW WATCH	PAGE 2
2	SETTING THE TIME	PAGE 3
3	SETTING THE DATE	PAGE 3
4	CHRONOGRAPH DISPLAY	PAGE 4
5	ADJUSTING THE CHRONOGRAPH HANDS	PAGE 4
6	CARING FOR YOUR LIV SWISS WATCH	PAGE 5
	CLEANING	PAGE 5
	CONDENSATION	PAGE 5
	WATER RESISTANCE	PAGE 5
	CRYSTALS	PAGE 5
	STRAPS IN LEATHER, FABRIC AND PYTHON/ALLIGATOR SKIN	PAGE 6
	SILICONE STRAPS	PAGE 6
7	FAQ	PAGE 6

1 PARTS OF YOUR NEW WATCH

THE MOVEMENT

Your chronograph is fitted with a quartz movement which is powered by a battery. Its time measuring device, known as its regulator, is a quartz crystal. An electrical current makes the crystal consistently vibrate at 32,768 times per second, a very high frequency. This provides the movement with near perfect precision, meaning that it will only vary a few seconds each period. This quartz movement is made in Switzerland, and is one of the most accurate and reliable of its kind. It has outstanding resistance to magnetic fields and shocks.

BATTERIES

The batteries for LIV - Swiss Watches quartz movements have life spans of approximately 54 months.



A	Hour Hand	F	30 Minute counter to chrono
B	Minute Hand	G	Second hand to chrono
C	Second Hand	H	1/10 of a second hand to chrono
D	Date Display	I	Start/stop function
E	Crown	J	Reset Push Button

2 SETTING THE TIME

1. Unscrew and pull the crown out to position III.
2. Turn the crown to set the time.
3. Push the crown back to position I and tightly screw it back in.*

*Failure to tightly screw it back in may result in water damage.

3 SETTING THE DATE



1. Unscrew and pull the crown out once to position II.
2. Turn the crown to set the date.
3. Push the crown back to position I and tightly screw it back in.

*Failure to tightly screw it back in may result in water damage.

4 CHRONOGRAPH DISPLAY



5 ADJUSTING THE CHRONOGRAPH HANDS



1. Unscrew crown and pull it twice to position III.
2. Hold both top and bottom buttons until the second hand of the chronograph does a complete turn indicating you are in set up mode.
3. Use the top button to adjust any of the chronograph hands. Use the bottom button to switch between the different hands.
4. To leave set up mode, push the crown back to position I and tightly screw it back in.*

*Failure to tightly screw it back in may result in water damage.

6 CARING FOR YOUR LIV SWISS WATCH

CLEANING

Clean your watch regularly as follows; this will maintain its esthetic appeal and ensure it stays in good working order.

- Ensure that the crown is completely screwed down before you get started.
- If the seals in your watch have been tested and changed within the last 12 months by LIV - Swiss Watches or an authorised LIV - Swiss Watches service center, then you may use a soft brush with mildly soapy water to clean case, then rinse it off with clear water and dry it with a soft cloth. If your watch is
- fitted with a fabric, alligator, leather or python skin strap, take care not to get it wet.
- If you have any doubts whatsoever about the water resistance of your watch, simply clean it with a soft brush, and then dry it.
- Avoid contact with detergents, solvents, cosmetics or any other chemical product, as these may damage the water-resistant gaskets and the bracelet.

CONDENSATION

A small amount of condensation may form under the crystal of your watch if there is a sudden temperature change. This mist will disappear by itself and will not impact the watch function. If the condensation persists, please contact LIV - Swiss Watches or an authorized LIV - Swiss Watches dealer.

WATER RESISTANCE

Given the nature of rubber seals, water resistance can not be a permanent condition. The rubber seals are designed to prevent water entry, however the fact that they are under constant pressure means that over time they will deteriorate. It is therefore necessary, throughout your watch's warranty coverage period, to have the water-resistance tested by LIV - Swiss Watches or an authorized LIV - Swiss Watches repair center every two years after the date of purchase. These tests are conducted free of charge. The International Warranty does not cover problems with water resistance and associated consequences if periodic water-resistance tests have not been conducted every two years following the date of purchase.

CRYSTALS

The crystal in your watch may be coated with an anti-reflective treatment (single or double), to make the time more readable. Marks may appear due to normal wear and tear of the watch, and are not covered by the International Warranty. The coating will be sufficient if you use your watch normally.

STRAPS IN LEATHER, FABRIC AND PYTHON/ALLIGATOR SKIN

Be sure to avoid letting the watch get into contact with water. Please note that no matter how careful you are with leather, it is a living material and its color will naturally (slightly) fade or darken over time. Leather straps should be cleaned with a dry, soft cotton cloth. Avoid any abrasive products during cleaning.

SILICONE STRAPS

Since silicone attracts dust, there is an anti dust coating on the band which makes the silicone strap matte. It is normal for that coating to start coming off after approximately 6 months of everyday wear. The strap will begin to appear shiny as time progresses.

7 FAQ

Does the 1/10 of a second dial of the chrono stop after 30 seconds?

It only stops SPINNING after 30 secs, but it is still calculating; the indication will show once you stop/pause the stop watch.

I've been setting the date at all times of the day and night but it always changes date at noon instead of midnight. What should I do?

Your watch set to PM instead of AM – it's a 12 hour clock. So for example, your 11 AM is set to 11 PM. The date changes between 11 PM and 1 AM. You simply need to bring the time forward by 12 hours.